

Instruction Guide: Irrigation Water Sampling



Analysis includes:

Water pH	Total Dissolved Solids	Electrical Conductivity (ECw)	Sodium Absorption Ratio
Hardness	Sodium	Phosphorus	Manganese
Bicarbonate	Chloride	Potassium	Iron
Carbonate	Boron	Magnesium	
Nitrate	Sulfate	Calcium	

Steps for collecting and shipping water samples:

1. Use a clean plastic container. Rinse the bottle (including the lid) several times with the water to be tested. Harris Laboratories provides complimentary sampling supplies, including clean plastic bottles. Call today.
2. To reflect the water quality at the time of application, collect sample from the pumping station or within the irrigation system.
3. If a system of irrigation wells (ground water) is being used, sample each well separately and identify each sample's source. This will qualify the water specifically from each well. (This is important if pumping into a holding pond.)
4. When collecting a sample from the irrigation system, let the water run for two to three minutes before collecting the sample. (This will purge static water from the system.)
5. When sampling from a pond, collect water from the pumping station, if possible. Remember to let the pumping station water run for two to three minutes before collecting the sample. DO NOT collect the water from the side of the irrigation pond. Sediment will act as a contaminant.
6. Fill the bottle and eliminate all head space. Be sure the lid is tight so that samples do not leak during transit. Laboratory needs at least 125 ml (about 4 ounces) of water.
7. DO NOT use glass containers.
8. If possible, collect and ship sample(s) the same day.
9. Clearly identify all bottles and complete necessary paperwork before shipping. Laboratory information sheets are available at the Harris Laboratories Website, harrislabs.agsource.com.



**AgSource
Harris Laboratories**

A Division of Cooperative Resources International

Copyright © by AgSource Harris, a Division of Cooperative Resources International

Email: harrislabs@agsource.com | Phone: (402) 476-0300 | harrislabs.agsource.com
300 Speedway Circle – Unit #2 | Lincoln, NE 68502

